

Enter Code to
Arm System



PowerSeries

Ready Armed Trouble




LCD Display



- Stay
- Away
- Chime
- Reset
- Exit

Numeric Keypad

System Status Lights



Function Keys



Emergency Keys